



## Cleaning Instructions

### **Cleaning of the internal parts (daily):**

1. Turn off power;
2. Remove product, display plates and grids, food scraps;
3. Check that fan blades are not running;
4. Wash with warm water and mild detergent/disinfectant;
5. Keeping all electrical parts away from water;
6. Dry every part completely;
7. Turn power back on and wait for correct temperature to be reached before loading the case;

### **Cleaning of the external case (daily):**

1. Wash all external parts with warm water and mild detergent/disinfectant;
2. Rinse with clean water and dry with soft cloth;
3. Do not use abrasive products or solvents;
4. Do not spray water or detergent on electrical parts;
5. Do not use on methacrylate (plexiglass) parts;

**Regularly clean the drip pan and drain.**

**WA DEALER  
PRACTICAL PRODUCTS PTY LTD**

PH: 08 9302 1299  
51 Paramount Dr Wangara WA 6065  
[sales@practicalproducts.com.au](mailto:sales@practicalproducts.com.au)  
[www.practicalproducts.com.au](http://www.practicalproducts.com.au)