

POPCORN MACHINE INSTRUCTIONS

YOU WILL NEED:



Small bowl



Large bowl



Dessert Spoon



Coffee Mug



Sunflower Oil



OPERATION

1. Turn kettle heater on (large black switch). Allow to warm for three minutes;
2. Put oil into bowl (just enough to coat base – too much will make the popcorn go soggy). Allow 1 min to warm;
3. Add one coffee mug of corn and one dessert spoon of butter salt (less or more to suit your own taste);
4. Close the lid of the kettle bowl;
5. Turn the Agitator switch on (left hand green switch);
6. Turn on light/warmer (right hand green switch);
7. Leave the doors open while the corn is popping;
8. When popping slows down and most of the kernels have popped, turn the bowl and dump the corn with a gentle tap. This will ensure all corn kernels to come out of the bowl otherwise they will burn in the next batch;
9. Add more oil (if required) and repeat the process for up 6 batches;
10. Keep the doors closed to ensure the popcorn remains fresh.
11. Clear out the crumb tray at the bottom of the machine on an as needs basis;

CLEANING

1. Clean the inside of the pop corn machine box with a sponge and soapy water;
2. **Please do not clean the bowl of the kettle as water will damage the unit.**

If you do have any queries please call 9377 3325 seven days